# MTK\_WCT\_V306 User Manual

### **General Description and Name**

This scheme Implements the skip block method for bad block handling. The whole partitions of the customer's image are divided into 2 kinds: Code image and FS image(File system image). Here, the code image is also divided into several partition and the FS image has only one partition. But in the FS image, it is divided into several regions. Every region has 256 blocks.

## **Relevant User Options**

The following special features on the special features tab apply to this scheme. The default values might work in some cases but please make sure to set the right value according to your system.

Please note only the below special feature items are related to this scheme and ignore any others. If any of below items doesn't exist, please check whether the right version has been installed or contact Data I/O for support by submitting Device Support Request through this address:

http://www.dataio.com/support/dsr.asp

<u>Bad Block Handling Type</u> = "MTK\_WCT\_V306"

<u>Spare area</u>: Please refer to "Description of common NAND special features.pdf". *Normally set as* "*ECC*" *for this BBM*.[Default 'Disabled']

#### **Special Notes**

The FS image in the customer's image file is the File system.

#### **Revision History**

V1.0 Date: 2009-12-22 Create this spec.

### **Appendix**

You can get the file "Description of common NAND special features.pdf" from http://ftp.dataio.com/FCNotes/BBM/